




we create sustainable outdoor living

L99

ARMLESS CHAISE LOUNGE


Box#1 - L99S

Box#2 - L99B




L99S BOX INCLUDES:

Ⓐ x1




Ⓔ x2




L99B BOX INCLUDES:


Ⓐ x1




Ⓓ x2




Ⓒ x1




Ⓕ x29



Ⓖ x5




Ⓗ x5



FASTENER SCALE TO 1:1



**KEEP THE CARDBOARD
TO AVOID ANY SCRATCH
DURING ASSEMBLY**



#2



7/16"
WRENCH







www.crpproducts.com

1

Ⓒ x1

Ⓔ x2

Ⓕ x8



**MAKE SURE TO
ROTATE OUTSIDE
BEFORE FASTENING Ⓔ**

FLUSH OUTSIDE EDGES



2

Ⓐ x1

Ⓑ x1

PLACE Ⓐ AND Ⓑ AS SHOWN.

ALIGN BOTH




**KEEP THE CARDBOARD
TO AVOID ANY SCRATCH**

3

Ⓒ x4



Ⓓ x4



**INSERT THE BOLT Ⓒ BEFORE
TIGHTENING THE NUT Ⓓ FOR
EASY ASSEMBLY.**




$\frac{7}{16}$ "
WRENCH



4

ⓕ x8

MAKE SURE THIS IS ALIGN





MAKE SURE THIS IS ALIGN


5

ⓓ x1

ⓕ x6



NOTE:
3 SCREWS EACH SIDE



FLUSH THIS



6

ⓓ x1





ⓕ x6

NOTE:

3 SCREWS EACH SIDE



ROTATE FOR DIFFERENT
BACK REST POSITION



NOTE:

1 EXTRA FASTENER ⓕ, ⓖ, ⓓ

